

eXact® LEADQuick™

The new eXact® LEADQuick™ Advanced Photometer from Industrial Test Systems, Inc. (ITS) is the perfect metre for all your water quality testing needs. No visual colour matching required means the eXact® LEADQuick™ takes the guesswork out of water testing.

- **Direct read parameters: Lead in Paint, Lead in Water, Mercury in Water, and Cadmium in Water.**
- **Easy-to-use eXact® Strip/Photometer reagent delivery system (US Patent #7,333,194) delivers reagents safely without the need to count drops or crush tablets**
- **0.01 ppm (mg/L) precision with no visual colour matching required**
- **Waterproof metre (IP-67) and it floats**
- **2-Year warranty with satisfaction guarantee**
- **Automatic test timer & 120 test memory (saves last 20 tests per menu)**
- **Autocalibrated metre**
- **No-slip grip housing and simple 3-button control**
- **Lightweight (weighs only 6 oz with batteries installed)**
- **Environmentally friendly (recyclable parts and uses 60% less reagents than 10mL sample tests)**
- **Private labeling and menu customization available**

**WATERPROOF
(IP-67)**



TECHNICAL SPECIFICATIONS:

Measurement Method:	Photometric Light Source: Light Emitting Diode (LED)
Wavelength:	476 nm
Memory:	20 tests per menu; 120 total
Programmed Tests:	Lead in Paint, Lead in Water, Mercury in Water, and Cadmium in Water
Photometric Precision:	.001
Display:	3-digit customized liquid crystal display with annunciators
Cell Pathlength:	20mm
Cell Chamber:	Custom-molded, proprietary, PET plastic fused into chamber, non-removable
Sample Required:	4 mL (0.13 oz)
Reagent System:	Utilizes patented eXact® Strip Micro reagent delivery system
Operating Temperature Range:	0 - 50°C (32° - 122°F)
Power Supply:	(4) AAA alkaline batteries
Battery Life:	>2000 tests with alkaline batteries
Electromagnetic Compliance (EMC):	Emitted Interference - EN 61326; Immunity to Interference - EN 61326
Waterproof Rating:	Exceeds IP67
Instrument Weight:	140 g (5 oz)
Instrument Dimensions:	5 (W) x 3.5 (D) x 16.5 (H) cm; (2 x 1.4 x 6.375 in)
Government Compliance:	European CE Mark

For more information about this and our complete line of test strips, reagent and water quality testing devices, please call or email as listed below.



ITS Europe, Ltd.
 The UK Centre for Homeland Security
 Building 7, Chilmark
 Salisbury, Wiltshire SP3 5DU UK
Tel: 0 (+44) 1722 717911
Fax: 0 (+44) 1722 717941
 sales@sensafe.com
 www.sensafe.co.uk